

To attach the Scombi roof bag to the roof of your vehicle using the grip hooks:

1. If you don't have roof rails, you must use the 4 grip hooks provided to attach the Scombi roof bag to your vehicle's roof. These grip hooks fit on most vehicles, and can also be purchased separately.
2. Open the vehicle door and pull down the rubber seal from around the door frame. In most vehicles, this seal is stuck on to the frame by pressure alone, and is not glued on.
3. Fit the grip hook onto the upper part of the vehicle's door frame on the car. The grip hooks are specially designed to attach to the door frame in one direction only so the loop side always faces out. You can't attach them the wrong way.
4. Now press the rubber seal back into place over the attached grip, and close the car door so that the loop is on the outside.
5. Repeat these steps for each of the 4 grip hooks (2 at the front - one on each side, and 2 at the back-one on each side), and you're ready to strap your Scombi roof bag to your vehicle.